


## AIRNEXUS VRV32 CONTROLLER WIRING SCHEMATIC



CAT6 LAN

## IMPORTANT TO NOTE


F1+F2 location varies by Daikin unit type: - Daikin VRV systems have F1+F2 located on OUTDOOR CONDENSER.

- Daikin Standalone (1:1) systems have F1+F2 located on INDOOR FCU.

All bus cable must be 2-core shielded cable, recommended 0.75mm<sup>2</sup>.

Maximum number of units that can be connected to Airnexus VRV32 controller is 32 fan coil units.

F1+F2 DAIKIN BUS



0000





Unit configuration used above is for illustration purposes